




# CashCode®

A division of **CRANE** PAYMENT SOLUTIONS



## MSM-MD8010

### Software description

CURRENCY:

**10, 20, 50, 100, 200, 500, 1000 Moldovian Lei (MDL)**  
(see **Bill Set Description BSD-MDL7-A** for more details)

EXTERNAL COMMUNICATION INTERFACE:

### MDB interface



# CashCode®

A division of **CRANE** PAYMENT SOLUTIONS

2720 Steeles Avenue West, Units 2-3, Concord, ON, Canada, L4K 4S3

TEL: (905) 303-8874, 1(800)-584-2633

FAX: (905) 303-8875, 1(800)-593-2633

Web Address: [www.cashcode.com](http://www.cashcode.com)

Email: [support@cashcode.com](mailto:support@cashcode.com)

EXTERNAL COMMUNICATION INTERFACE FEATURES:

**MDB INTERFACE**

- **Country Code = 1498h**
- **Decimal Place = 1**
- **Scaling Factor=100**

DIP SWITCHES SETTING:

<b>SW#1</b>	<b>ON state</b>	<b>OFF State</b>	<b>Default Setting</b>
SW 1.1	10 Lei Enable	10 Lei Disable	ON
SW 1.2	20 Lei Enable	20 Lei Disable	ON
SW 1.3	50 Lei Enable	50 Lei Disable	ON
SW 1.4	100 Lei Enable	100 Lei Disable	ON
SW 1.5	200 Lei Enable	200 Lei Disable	ON
SW 1.6	500 Lei Enable	500 Lei Disable	ON
SW 1.7	1000 Lei Enable	1000 Lei Disable	ON
SW 1.8	Reserved	Reserved	ON
<b>SW#2</b>	<b>ON state</b>	<b>OFF State</b>	<b>Default Setting</b>
SW2.1	Four Way	One Way	ON
SW2.2	Stacker Up	Stacker Down	ON
SW2.3	High Acceptance	High Security	ON
SW2.4	To work with a "Host Machine Controller"	Service Mode	ON

OPTIONAL ACCESSORIES AND DOCUMENTS

- **CashCode Bill Set Description** – **Part# BSD-MDL7-A**
- **CASHCODE Bill Validator MDB Protocol Interface Descriptions** – **Part# MAN-MDB**
- **CASHCODE Interface PC Emulator** – **Part# OPT-SW- INT**